



PORSCHE



Macan Quick Start Guide

Macan
Macan S
Macan GTS
Macan Turbo
Macan Turbo w/ Performance Package

Quick Questions & Answers


Please do not read while driving.

Opening/Unlocking/Locking Vehicle	3
What are the functions of the Remote Entry System?	3
How do I save my personal settings in my vehicle and key (optional)?	4
How do I protect against theft or intruders?	4
How do I open and close the power tailgate?	5
How do I adjust the opening height of the tailgate?	6
Porsche Intelligent Performance	7
I notice more tire noise and tire wear than I've experienced with some other cars. Why is that?	7
What should I know about the Tire Pressure Monitoring System?	7
Is there anything I should know about the brakes on my Macan?	7
What exactly do the SPORT and Sport Plus (optional) buttons do?	8
What should I know about the Auto Start Stop Feature?	8
How do the ParkAssist and Rear View Camera systems work?	9
What should I know about Lane Change Assist (LCA) (optional)?	9
How does Lane Keep Assist (LKA) (optional) work?	10
Why is the ignition located on the left?	10
Instruments and Controls	11
What are the simplest ways to use the Air Conditioning System?	11
How do I activate the Windshield Wiper System?	12
How do I engage and/or disengage Cruise Control or Adaptive Cruise Control (optional)?	12
How do I turn on the heated steering wheel (optional)?	13
How do I operate the multi-function display?	13
How do I set the time in the vehicle?	13
How do I apply the electric parking brake?	13
What do I need to know about the headlights?	14
How do I fold the rear seats?	14
Where are the cupholders in the Macan?	14
How do I operate the Panoramic Roof System (optional)?	15
How do I set the time and date in PCM?	15
Communication & Audio Controls	16
How do I operate the Porsche Communication Management (PCM) System?	16
How do I activate Bluetooth® Hands-Free Equipment for use with my cell phone?	17
What should I know about Apple® CarPlay™?	17
How do I operate the Navigation System?	18
Where are the USB/iPod® and AUX interfaces located?	19

This document only summarizes some of the most basic features of your new Panamera vehicle. The Owner's Manual supplied with your car contains much more detailed information, as well as critically important safety instructions and warnings. For your own safety, DO NOT RELY ONLY UPON THIS SUMMARY. Please read your entire Owner's Manual, and do not hesitate to call us at 1-800-PORSCHE with any questions.

Opening/Unlocking/Locking Vehicle

What are the functions of the Remote Entry System?



- A** Unlock the vehicle
- B** Lock the vehicle
- C** Open tailgate and unlock doors
- D** Emergency key
- E** Panic button

Unlocking	Press button A on the key once. The emergency flasher emits one flash. The driver's door and tailgate can be opened. Press button A on the key twice. The emergency flasher emits one flash. All vehicle doors and the tailgate can be opened. Press button C on the key for approximately 1 second. The rear tailgate is unlocked and will open.
Locking	Press button B on the key once. The emergency flasher flashes twice and a signal will sound. The doors are locked.
Porsche Comfort Access (optional)	While carrying the key in your pocket or purse: • Unlocking: Grip the door handle fully. The respective door can be opened, and the emergency flasher flashes once. When the driver's door is unlocked, the tailgate is unlocked too. • Locking: Touch proximity sensor F on the door handle. An acoustic signal will sound twice, and the emergency flasher flashes twice. 

HELPFUL TIP: To turn off the alarm, press button **A** on the key to unlock the car. If persons or animals will remain in the vehicle, press button **B** on the key **twice within 2 seconds**, or for vehicles with Porsche Comfort Access, press button **F** on the door handle **twice within 2 seconds**. The doors can be opened from inside by **pulling once** on the front inner door handle or by pulling **twice** on the rear inner door handle. Reference "Alarm System and Theft Protection" in your Owner's Manual for more information.

Opening/Unlocking/Locking Vehicle

How do I save my personal settings in my vehicle and key? OPTIONAL

With the ignition on, press the memory button **SET** and then press button **1** or **2** on the door panel within 10 seconds until an acknowledgement signal sounds. The ergonomic settings (seat, mirrors, steering wheel) are now stored on the corresponding button. Or press the memory button **SET** and then press button  to store the ergonomic and comfort settings (PCM, temperature, instrument cluster) on one of the keys.



To retrieve the individual preferred settings stored on the buttons, press and hold the corresponding button until the seat movement and other adjustment operations have been completed. The settings stored on the key are retrieved automatically after unlocking the car with this specific key.

HELPFUL TIP: If you would like to store the current settings on your key each time you lock your vehicle, please activate the “Auto Memory” function in the multi-function display under:

VEHICLE > SETTINGS > LOCKING > Auto Memory

If multiple drivers use the vehicle, assign a button to each driver and save the individual settings on a specific key via: **SET** 


How do I protect against theft or intruders?

Your Macan automatically locks itself after you switch on the ignition or drive off, depending on the settings in the multi-function display. You can adjust this function in the multi-function display and configure when and which vehicle doors automatically lock. You will find these settings in the multi-function display under:

VEHICLE > SETTINGS > LOCKING > Door Lock or Door Unlock

If you wish to allow the doors to subsequently be opened from the outside, the vehicle must first be unlocked from the interior cabin by pressing the unlock button **1** on the door panel.

HELPFUL TIP: Pressing the lock button **2** will lock all doors and the tailgate, and the light-emitting diode **A** on the button will be illuminated. The doors can manually be unlocked and opened from inside by pulling once on the front inner door handle or by pulling twice on the rear inner door handle. Pressing the unlock button **1** will unlock all doors and the tailgate, and the light-emitting diode **A** will go out. Please note, the central locking button does not lock or unlock the fuel filler flap.




How do I open and close the power tailgate?

There are multiple ways to open and close the power tailgate:

- **Open/close from the tailgate:**

To open, press the release button **1** in the windshield wiper base. The tailgate opens automatically. To close, push button **2** on the trim panel of the tailgate. Button **2** will only close the tailgate, but the vehicle will not be locked once the tailgate closes. To lock the vehicle after the tailgate has closed, press button **B** on the key. For vehicles equipped with Porsche Entry & Drive, pressing button **3** on the trim panel of the tailgate will close the tailgate and lock the vehicle.




- **Open/close from the driver's door:**

To open, briefly press button **4** on the driver's door. To close, with the ignition on, press and hold button **4** on the driver's door.



- **Open using the key:** With the ignition off, press button **C** on the key for approximately 1 second. If the vehicle is locked, using the key to open the tailgate will unlock the vehicle (either the driver's door or all doors will then be unlocked, depending on how the door locking/unlocking settings are configured within the multi-function display).

HELPFUL TIP: The tailgate opening or closing operation can be interrupted by pressing button **2** or **3** in the trim panel of the tailgate, button **4** on the driver's door, or button **C** on the key.





Opening/Unlocking/Locking Vehicle

How do I adjust the opening height of the tailgate?

The tailgate opening height can be adjusted to a desired opening height.

- **Step 1:** Stand behind the vehicle and open the tailgate.
- **Step 2:** Press button **C** on the key or button **D** on the tailgate trim panel to stop the automatic opening operation.
- **Step 3:** Move the tailgate up by hand until the desired opening height is reached.
- **Step 4:** Press and hold button **D** in the trim panel of the tailgate for approximately 3 seconds until an acknowledgement signal sounds. The opening height of the tailgate is now programmed.

HELPFUL TIP: To adjust the full opening height again, move the tailgate by hand past the manually set opening height until the tailgate is fully opened. Press and hold button **2** in the trim panel of the tailgate until the acknowledgement signal sounds again.



Notes

.

.

.

.

.

.

.

.

.

.

Porsche Intelligent Performance

I notice more tire noise and tire wear than I've experienced with some other cars. Why is that?

Porsche cars are engineered for a high level of performance and are also designed to ensure safety, driving pleasure, comfort and daily use. The hardness of the tire depends on the tire's temperature, as well as the compound specifications and the tread pattern of the tire. The side effects of these tire constructions may create louder noises while making a sharp turn when the tire is cold, such as pulling out of a parking spot.

HELPFUL TIP: All tires slowly lose air, and tire pressure also changes considerably when a tire heats up as a result of being driven. To keep tire noise and wear to a minimum, check tire pressure frequently and top off to recommended pressure.

What should I know about the Tire Pressure Monitoring System?

As an added safety feature, your vehicle has been equipped with a Tire Pressure Monitoring System (TPMS) that illuminates a low tire pressure warning light when one or more of your tires is significantly under-inflated.

When the low tire pressure warning light illuminates, you should stop and check your tires as soon as possible and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure.



HELPFUL TIP: While the vehicle is stationary, you can check the tire pressure within the multi-function display under:

Tire Pressure > Fill Info

Fill info shows the difference between the actual tire pressure and the required tire pressure.

Is there anything I should know about the brakes on my Macan?

Porsche vehicles utilize a high performance braking system that incorporates materials conducive to increased braking performance, which have a tendency to emanate increased acoustics. A few hard stops should reduce this condition.

HELPFUL TIP: Brake dust is a normal result of high performance friction materials and does not affect braking performance. Wear on the different components of the braking system, such as brake pads and brake disks, depends to a great extent on the individual driving style and the conditions of use and therefore cannot be expressed in actual miles on the road.

Porsche Intelligent Performance

What exactly do the Sport and Sport Plus (OPTIONAL) buttons do?

The Macan is equipped as standard with a **SPORT** button. When Sport mode is switched on, the button illuminates and the PDK (Porsche Doppelkupplung) transmission switches to a sporty, gear-changing map, shortened shift times and earlier initiation of braking downshifts. Drivetrain and chassis components, depending on vehicle equipment, are also adjusted towards greater agility and driving performance.

For vehicles equipped with Sport Plus mode (optional), the PDK transmission changes to a shift program designed for driving on race circuits and the gear-changing performance is enhanced significantly again, compared to Sport mode.



HELPFUL TIP: When driving in Sport or Sport Plus mode, Auto Start Stop is deactivated.

What should I know about the Auto Start Stop feature?

The Auto Start Stop feature stops the engine automatically when the vehicle is stopped or during a stop at a walking pace (for instance, when in traffic) to reduce fuel consumption. When the engine switches off automatically, the ignition stays on and all safety functions are still available.

- **Automatic Engine Start:** If Auto Start Stop has stopped the engine, the engine will restart if the footbrake is released, the accelerator is pressed, the steering wheel is moved, or the car requires additional energy from the engine (for example A/C, defrost, lights, etc.).
- **Default On:** Auto Start Stop is automatically activated whenever the vehicle is turned on. To turn off the feature, press the button. The indicator light on the button will turn on. The engine will not automatically shut off if the button is illuminated, Sport or Sport Plus mode is active, PSM is switched off, if adjusting the chassis level, or the car requires additional energy from the engine (for example A/C, defrost, lights, etc.).



HELPFUL TIP: When Adaptive Cruise Control (optional) is switched on, the engine starts automatically if the vehicle in front drives off, the accelerator is pressed, the speed and distance control is resumed using the control stalk, or if Adaptive Cruise Control is switched off.


How do the ParkAssist and Rear View Camera systems work?

ParkAssist visually and audibly indicates to the driver the distance between the vehicle and an obstacle during parking and maneuvering using ultrasound sensors.

ParkAssist is activated automatically while driving at low speeds and is deactivated at a speed of more than approximately 9 mph. It can be manually deactivated by pressing button **A** on the overhead console.

ParkAssist settings can be managed from your Porsche Communication Management (PCM) System:

ASSIST > SET > ParkAssist




The Rear View Camera is automatically activated when the reverse gear is selected.

What should I know about Lane Change Assist (LCA)? OPTIONAL

Lane Change Assist (LCA) uses radar sensors to help warn the driver about vehicles that are approaching from the rear or are located in the blind spot. This applies when overtaking other vehicles and when being overtaken. Integrated warning indicators in both door mirrors light up as soon as a dangerous situation is identified and changing lanes seems essential.

The warning indicator **B** on the left exterior mirror assists the driver in changing into the left lane, while the warning indicator on the right exterior mirror assists the driver in changing into the right lane.



The system can be turned on and off by toggling indicator **A** on the driver's door panel.

HELPFUL TIP: Brightness of the indicator can be adjusted from the multi-function display by selecting:

VEHICLE > SETTINGS > ASSIST. SYSTEMS > LCA

How does Lane Keep Assist (LKA) work? OPTIONAL

The Lane Keep Assist (LKA) is a highway feature that actively supports the driver by initiating corrective steering intervention to bring the vehicle back into the lane when it detects that the driver is inadvertently straying from the lane or is changing lanes without indicating.

The system also alerts the driver by issuing an acoustic and visual warning. The driver can override the corrective steering intervention at any time. A camera detects the lane lines so that the course of the lane can be continuously recalculated. (If the system assesses the distance from the lane lines as critical at a speed of over approx. 40 mph (65 km/h), it initiates corrective steering intervention and the vehicle is guided back into the lane).



In addition, a warning tone sounds when the vehicle drives over the lane marking and the lane line in question is identified on the multi-function display of the instrument panel.

Lane Keep Assist is a highway feature that is not suitable for sporty driving on curvy roads. The feature can be switched on and off by pressing button **A**. If the feature is on when the vehicle is turned off, the next time the vehicle is started, the feature will be on again. When on, the vehicle must be traveling at speeds of 37 mph or greater to activate the feature.

HELPFUL TIP: It is possible to adjust the volume of the system within the multi-function display by selecting:

VEHICLE > SETTINGS > ASSIST. SYSTEMS > Lane Keep Assist.

Why is the ignition located on the left?

The ignition in every Porsche vehicle is located on the left in honor of our rich racing past. In the Fifties, European racing events often used a “Le Mans Start”, where the drivers sprinted across the track to their cars. Porsche gained a small but vital advantage by placing the ignition switch on the left, since the race car driver could start the engine while operating the gear lever.


HELPFUL TIP: The left-handed ignition is as much a part of Porsche lore as the pronunciation of the company name (spoken “Por-sha”, in two syllables).

Instruments and Controls

What are the simplest ways to use the Air Conditioning System?

- **To activate automatic air conditioning:** Press button **H** to activate the cooling function for the driver or button **O** for the passenger.
- **To manually adjust the temperature:** Press button **C** up (warmer) or down (colder) for the driver or button **J** for the passenger.
- **To increase or decrease fan speed:** Press button **D** up (more) or down (less) for the driver or button **K** for the passenger.
- **To manually adjust air distribution:** Press buttons **E, F** and/or **G** to select air distribution for the driver or buttons **L, M** and/or **N** for the passenger.
- **To activate A/C MAX mode:** Press button **Q** to cool the passenger compartment at maximum power. The interior temperature is not regulated automatically when A/C MAX mode is activated.
- **To recirculate air:** Press button **B**.
- **To defrost the windshield/rear window:** Press button **A** to defrost the windshield and button **I** to defrost the rear window.
- **To SYNC climate throughout cabin:** Press button **P** to activate SYNC mode. Press button **H** or **O** or adjust the temperature on the passenger's side using button **J** to deactivate SYNC mode.

HELPFUL TIP: In SYNC mode, the temperatures on the driver's and passenger's sides are synchronized. When SYNC mode is on, driver and passenger temperatures are both regulated via the TEMP button **C** on the driver's side.





NOTE: Some features described in this document are optional equipment and may not be fitted to your automobile.

How do I activate the Windshield Wiper System?

Front Wiper Operation:


- **Automatic (rain sensor):** Raise the stalk to position **1**. To adjust the rain sensor, move switch **B** in the stalk upwards (wipe more often) or downwards (wipe less often).
- **Slow wipe:** Press the stalk to position **2**.
- **Fast wipe:** Press the stalk to position **3**.
- **One wipe:** Briefly move the stalk to position **4** (holding stalk in position **4** accelerates wiping action).
- **Spray and wipe:** Pull stalk to position **5** and hold briefly.




Rear Wiper Operation (optional):

- **Wipe:** Push switch **B** up to detent position **INT** to activate intermittent operation.
- **Spray and wipe:** Push switch **B** all the way up or down and hold briefly.

How do I engage and/or disengage Cruise Control and the Adaptive Cruise Control? OPTIONAL



Cruise Control



Adaptive Cruise Control

Both Cruise Control and Adaptive Cruise Control (ACC) are operated using the control stalk at the bottom left of the steering wheel.

- Push button **A** to switch cruise control on/off
- Push forward **1** to set/increase desired speed
- Pull **2** to reduce desired speed
- Push down **3** to interrupt (OFF)
- Push up **4** to return to set speed (RESUME)

ACC actively increases or decreases vehicle speed, depending on both traffic and desired distance. The desired distance from the vehicle in front can be reduced or increased using switch **B** in the control stalk.

HELPFUL TIP: ACC also brings your vehicle to a complete stop and actively keeps it at a standstill when engaged; if the vehicle in front drives off, automatic speed and distance control can be resumed by using the accelerator pedal or the "Resume" function on the stalk.

How do I turn on the heated steering wheel? OPTIONAL

Press the button on the rear of the center steering wheel spoke. The message “Heated steering wheel on” or “Heated steering wheel off” appears on the multi-function display for 2 seconds.




How do I operate the multi-function display?

The multi-function display is operated via the steering wheel buttons:

Turning A: Navigate up/down in the menu

Pressing A: Select/confirm within the menu.

Pressing B: Moving back within the menu.



How do I set the time in the vehicle?

The current time is centrally adjusted for all clocks in the vehicle within the multi-function display under:

VEHICLE > SETTINGS > Date & Time

You will only need to set the time zone, as your vehicle receives the correct time via the GPS satellite signal. The time can be found on the lower status area of the multi-function display in the instrument panel and on the bottom right of the PCM screen.



How do I apply the electric parking brake?

The electric parking brake acts on the rear wheels and serves to secure the vehicle while parked.

Applying the parking brake: Pull button (P). The indicator light on button (P) and the brake warning light on the instrument panel come on.

Releasing the parking brake: With the ignition on, press the brake pedal and then press button (P). The indicator light on button (P) and the brake warning light on the instrument panel go out.




HELPFUL TIP: If the engine is running, the driver's door is closed and the driver's safety belt is fastened, it is still possible to drive off normally even though the parking brake is on. The electric parking brake detects the driver's intention to drive off and releases automatically. The indicator light on button (P) and the brake warning light in the instrument panel go out.

Instruments and Controls

What do I need to know about the headlights?


When the light switch is in the AUTO position, the automatic driving light assistant switches on the driving lights (low beam) automatically depending on the ambient brightness. If equipped with High Beam Assistant (optional), a camera detects the light sources of oncoming vehicles, vehicles in front, or city lights, and automatically selects between low beam and high beam. To activate High Beam Assistant, push the turn signal stalk once to the front pressure point **3**.



HELPFUL TIP: For High Beam Assistant to activate, the light switch must be in the AUTO position, it must be dark outside, the vehicle must be traveling at approx. 37 mph or greater, and High Beam Assistant must be selected in the multi-function display. High Beam Assistant can only be deactivated by pulling back the turn signal stalk when the indicator light  on the tachometer is lit.

How do I fold the rear seats?

The rear seat backrests are divided and can be folded forward individually to make the luggage compartment larger. The backrests on the left and middle rear seats (in direction of travel) are joined together. When you fold the left backrest forward, the middle backrest will also fold forward.




1. Ensure the rear headrests are down.
2. Press release button **A** and fold the backrests forward.

HELPFUL TIP: If the red marking **B** on the release handle is still visible, the backrest is not engaged correctly. Make sure that the red marking **B** on the release handle is no longer visible after the backrest has engaged. Release the backrest and engage it again if necessary.

Where are the cupholders in the Macan?


Two cupholders **A** are located in front of the driver/passenger armrest, and two additional cupholders **B** are located in the rear armrest, when folded down.



How do I operate the Panoramic Roof System? OPTIONAL

The Panoramic Roof System is operated using the  button in the overhead console. The button for operating the Panoramic Roof System has a two-stage function for all directions of motion.


- **First setting — manual operation.** If button **A** is moved to the first setting in one direction, the Panoramic Roof System is adjusted manually in the relevant direction. Adjustment stops when the button is released.
- **Second setting — one-touch operation.** If button **A** is moved fully to the second setting, the Panoramic Roof System is opened or closed automatically. Actuate the button again in any direction to stop the Panoramic Roof System at the desired position.



HELPFUL TIP: To protect the vehicle from direct sunlight, a roll-up sunblind is integrated in the Panoramic Roof System and can be adjusted by actuating rocker switch **B** in the roof console.

How do I set the time and date in PCM?

The time and date settings can be found on the bottom right of the Porsche Communication Management (PCM) screen. On the PCM system, press the **CAR OR HOME** **BUTTON** > **SET**  > **SYSTEM** > **DATE AND TIME**. Here there are several options:



- | | | |
|--------------------|----------------------|----------------------|
| • Auto time | • Date | • Time zone |
| • Time | • Date format | • Time format |

HELPFUL TIP: You will only need to set the time zone to automatic (Auto time), as your vehicle receives the correct time via GPS satellite signal. The time can also be found on the lower status area of the multi-function display.

Notes

.

.

.

.


.

.

Communication & Audio Controls

How do I operate the Porsche Communication Management (PCM) System?

- A.** Adjust volume, switch PCM on/off
- B.** Radio
- C.** Media and radio sources
- D.** Music and videos
- E.** Phone, news, and emails
- F.** Navigation
- G.** Vehicle and system settings
- H.** Map and traffic incidents
- I.** Main menus, sound settings, Porsche Connect app, Apple CarPlay™
- J.** Rotary push button (for controlling the PCM)
- K.** Undo button: Undo a operation, cancel a selection, or move up a level in the relevant menu
- L.** Settings dependent on main menu and sound settings
- M.** Setting the time
- N.** Touchscreen (to operate the PCM)
- O.** Connection Manager (connecting a phone, displaying WiFi settings and setting up a WiFi hotspot, connecting Bluetooth® devices, displaying Apple CarPlay™ and Porsche Connect App connection status)
- P.** Skip buttons (set track/station)



NOTE: Some features of the PCM may be optional equipment

How do I activate Bluetooth® Hands-Free Equipment for use with my cell phone?

You may connect your cell phone with the vehicle via Bluetooth®. We recommend that you do this together with your customer service representative at your authorized Porsche dealer. Pairing is as follows:




1. **Determine if phone is compatible with the vehicle by visiting www.porscheusa.com or contacting your authorized Porsche dealer.**
2. **Ensure your phone is on and Bluetooth® is activated. If not, please activate now via the phone's settings. For some phones, you may have to activate the Bluetooth® visibility.**
3. **Select the **CONNECTION MANAGER** by pressing either  or  in the left side of the footer on your PCM screen.**
4. **Inside the **CONNECTION MANAGER** select **"PHONE"**. Here you can search for your phone by selecting **"Search for a new phone"**. It may take a few moments for your phone to appear.**
5. **When your phone appears, accept or enter the Bluetooth® PIN code specified by the PCM on the phone to complete the pairing process.**

HELPFUL TIP: You can also manage phone settings from within the **PHONE** menu by pressing the **OPT.** button just below the PCM module > selecting **"SET PHONE"** > **"BLUETOOTH"**. Here you can add a new device in addition to the one paired (although only one can be used at a time), manage existing devices including deleting devices off of the PCM, deactivating Bluetooth® on the PCM, and set up a helpful reminder to not forget your phone upon leaving your Porsche vehicle.

What should I know about Apple CarPlay™? OPTIONAL


If equipped with an iPhone® device, Apple CarPlay™ is a smarter, safer way to use your iPhone® in your car. It takes the things you want to do with your phone while driving and puts them right within the PCM display. You can get directions, make calls, send and receive messages, and listen to music. This acts in a way that allows you to stay focused on the road ahead. To engage Apple CarPlay™ on your PCM, simply connect your iPhone® to the USB port found in the storage bin under your armrest. Once connected and terms are accepted on the PCM display, Apple CarPlay™ will appear on your PCM screen. To exit, simply press the Porsche icon on the display. To find out if your iPhone® is Apple CarPlay™ compatible, visit www.apple.com/ios/carplay.



Communication & Audio Controls

How do I operate the Navigation System?

- A.** Route guidance information, duration and distance to destination or arrival time.
- B.** Switch between scale display and auto zoom.
- C.** Center vehicle position on map.
- D.** Set map orientation to North up or direction of travel.
- E.** Call up map page menu.




- F. 3D:** 3D view (otherwise 2D view)
- G. Traffic:** Show or hide traffic information on the map. Prerequisite: Data connection is established.
- H. Traffic Flow:** Show or hide real-time Internet traffic information on accidents, road works, traffic flow information and other incidents. Prerequisite: Data connection is established.
- I. Show POI:** Show or hide points of interest on the map.




Searching an Address or Point of Interest (POI): The search functions can be accessed through the **NAV** button:

- J. Search or Online search:**
 - Enter search term (e.g. city, house number, street, name).
 - Select the correct entry from the list of suggestions.
- K. House number, Street, City or Country:**
 - Enter a destination address.
- L. Points of Interest:**
 - Select point of interest.
- M. Favorites** :
 - Scroll (swipe) to **CONTACTS** page.
 - Select entry from list.



Where are the USB/iPod® and AUX interfaces located?

The USB/iPod® and AUX interfaces are located in the storage compartment between the front seats.



Notes

Macan Quick Start Guide



The **Porsche iManuals** website **porscheownersmanuals.com** is your online interactive guide for all questions regarding the operation of your vehicle. Porsche Customer Commitment may be reached at **1-800-PORSCHE** for any questions or information on the Porsche owner services.

NOTE: Some features described in this document are optional equipment and may not be fitted to your automobile.

Dr. Ing. h.c. F. Porsche AG is the owner of numerous trademarks, both registered and unregistered, including without limitation the Porsche Crest®, Porsche®, Boxster®, Carrera®, Cayenne®, Cayman®, Macan®, Panamera®, Spyder®, Tiptronic®, VarioCam®, PCM®, PDK®, 911®, 718®, RS®, 4S®, 918 Spyder®, FOUR, UNCOMPROMISED®, and the model numbers and the distinctive shapes of the Porsche automobiles such as, the federally registered 911 and Boxster automobiles. The third party trademarks contained herein are the properties of their respective owners. All text, images, and other content in this publication are protected by copyright. No part of this publication may be reproduced in any form or by any means without prior written permission of Porsche Cars North America, Inc. Some vehicles may be shown with non-U.S. equipment. Porsche recommends seat belt usage and observance of traffic laws at all times.

© 2017 Porsche Cars North America, Inc. Printed in U.S.A.

Model Year 2018 Shown